

Instructions for use: Pre-Sewn Intercept Corrosion Control Cylinder Bags

- Place item inside bag. Use appropriate lifting equipment and observe all associated precautions during lifting. White side of bag is the outside surface, *the black side containing the active anti-corrosion material is the inside surface of the bag.*
- Make sure bag fits correction with enough overlap to allow welding. Use heat gun to weld bag closed. Wear appropriate safety equipment, welding gloves and safety glasses. Observe all associated safety precautions when using the heat gun.
- Use heat gun to shrink the bag, giving a snug fitting cover. Avoid shrinking too close to the sewn seams of the bag.
- Apply White UV-resistant tape to welded seams and sewn seams and to any penetrations (e.g., cradle legs, stands, etc.) to create watertight seals.
- Seal the sewn seams with a single layer of White UV Shrink Tape.
- Repair any accidental cuts, nicks and holes with waterproof White UV-resistant tape.
- *Tip:* Use clear heat-shrink pallet bag over the top of larger items to improve weather protection.
- *Tip:* Use desiccants inside the sealed object for longer-term storage.

